

SKY SCREAMER **FLYZONE**

Radio Control Plane

Easy, high-flying fun—at an affordable price!

From building to flying, everything about the Sky Screamer says easy—it's even easy to afford. Modelers as young as 8 will enjoy piloting this FlyZone favorite, and it's the perfect way to prepare for higher levels of R/C. After you see how easy and how much fun this plane is, you'll be "screaming" for more!



INCLUDES SPARE WING AND TAIL SET!

- Easy to hand launch—and so forgiving that it can recover from most minor pilot errors all by itself.
 - Advanced electronics control both climbing and steering, via the twin motors—no moving parts to bend, adjust or break.
 - Added conveniences include the extra wing, tail section and two spare props that are supplied.
-



Flight-ready in just a few minutes, the Sky Screamer comes with everything shown here; there's even a spare replacement wing and a DVD that illustrates final assembly steps and offers flight tips.



The Sky Screamer's twin motors and props are used for both thrust and steering, and are preinstalled for convenience. The rear-facing, "pusher" design helps protect the props from damage.

This self-contained field charger makes the flying fun nearly non-stop! It operates on "D" batteries, so it's totally portable, and recharges the plane's 4.8V NiMH battery in just 20 minutes.



Unlike "toy" airplane models, the Sky Screamer uses a hobby radio with quality features such as an LED that alerts to low battery power.

SPECIFICATIONS

Stock Number: HCAA2014

Wingspan: 27.5 in (699mm)

Fuselage Length: 23.5 in (597mm)

Flying Weight: 6.1 oz (173g)

Includes: 2-channel radio, (2) 130-size motors, 4.8V Nickel-Metal Hydride battery, 20-minute field charger, spare main wing and tail set, (2) extra propellers, instructional DVD, screwdriver, wrench

Requires: 8 "AA" batteries for the radio, 6 "D" batteries for the charger